



Depth stop

Depth stop for all saw blades. For accurate working at depth. Effective protection for blade and workpiece.

Contents: 1 adapter for attachment to the machine. 1 depth stop, 1 depth-adjustable guide block.

Can only be used with (A)MM 500 / 700.

Product number: 3 21 27 069 01 0

Suitable for the following tools

- | | | |
|--|---|---|
| <ul style="list-style-type: none"> > Cordless MULTIMASTER AMM 500 Plus Top AS > Cordless MULTIMASTER AMM 700 Max AS > Cordless MULTIMASTER AMM 700 Max Top AS > Cordless MULTIMASTER AMM 500 Plus AS > Cordless MULTIMASTER AMM 700 Max Top 4 Ah AS > MULTIMASTER MM 500 | <p>Plus</p> <ul style="list-style-type: none"> > MULTIMASTER MM 500 Plus (110 V) > MULTIMASTER MM 500 Plus Top > MULTIMASTER MM 500 Plus Top (110 V) > Cordless MULTIMASTER AMM 500 PLUS 4 Ah with nylon bag > Cordless MULTIMASTER AMM 700 Max AS 4 Ah | <p>with nylon bag</p> <ul style="list-style-type: none"> > Cordless MultiMaster AMM 500 PLUS AS (in box) > Cordless MultiMaster AMM 700 MAX AS (in box) > MULTIMASTER MM 500 PLUS Selection > MULTIMASTER MM 700 PLUS Selection |
|--|---|---|